



Installing PowerBook G4 Titanium Onyx Modem

Tools used in this guide

- [5mm Nut Driver](#) (1)
- [T8 Torx Screwdriver](#) (1)

Parts relevant to this guide


- [G4 Titanium Onyx or DVI 56k Modem](#) (1)

56k internal modem, standard on all models.



Step 1 - Keyboard

- Remove the battery.
- Turn the keyboard locking screw so that it is parallel to the space bar.
- Pull the keyboard release tabs toward you and lift up on the keyboard until it pops free.



Step 2

- Rest the keyboard face down on the trackpad area.
- Disconnect the keyboard connector from the logic board.



Step 3

- Your laptop should look approximately like this.



Step 4 - RAM

-
- Pull the RAM chip out.
- Repeat this process if a second RAM chip is installed.



Step 5 - Lower Case

- Turn the G4 over.
- Remove the eight T8 Torx screws from the lower case.



Step 6

- Using your thumbs, slide the lower case away from you.
- The lower case may stick in the front on a tab just above the center of the DVD drive. Be careful as you work the case off, or you may break the thin strip of plastic just above the drive.
- Lift the lower case off.





Step 7

- Your laptop should look approximately like this.




Step 8 - Airport Card

- Skip this step if your computer does not have an Airport card.
- Firmly grasp the plastic tab attached to the Airport card and pull up and to the left.
- Disconnect the antenna cable from the left side of the Airport card.



Step 9 - Hard Drive

- Disconnect the hard drive ribbon from the logic board using a spudger or the tip of your finger, removing tape as necessary.



Step 10

- To free the hard drive, remove the two T8 Torx screws from the right wall of the battery housing.



Step 11

- Remove the hard drive by gently grasping the orange ribbon cable and lifting the left edge up and out of the computer.
- There are four rubber bumpers that fit over the hard drive screws. Ensure that these bumpers come out when you remove the hard drive.



Step 12

- Your laptop should look approximately like this.



Step 13 - DVD Drive

- If your G4 has a CD-RW or Combo drive, the pictures in the following steps will not exactly match your computer.
- Before continuing, place a soft cloth on your work surface to rest the computer on. Turn the G4 over, making sure the DVD drive doesn't fall out. Place the computer on the cloth.



Step 14

- Bend the silver metal EMI clip so that it is vertical. This part may fall out after removing the DVD drive.
- The EMI clip is not essential for reassembling the computer. If the clip falls out, don't worry about putting it back in.



Step 15

- Turn the G4 over.
- Disconnect the orange DVD ribbon cable from the logic board using a spudger or the tip of your finger




Step 16

- Remove the DVD drive by lifting the right edge up and out of the computer.
- If you have a CD or any other object jammed in your optical drive, we have an [optical drive repair guide](#).



Step 17 - Modem

- Turn the G4 over.
- Using a 5 mm nut driver or needle-nose pliers, remove the hex nut from the modem.



Step 18

- Lift the modem out by pulling up and to the right.
- The plastic shielding on the modem may catch on the computer's case. Rocking the modem from side to side will help free the modem.





Step 19

- Disconnect the connector cable from the modem.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on Dec 13, 2010.

